

Service place	Open access loading place registered by GYSEV Zrt.								Loading track next to loading places						Restrictions, remarks
	Code of the service place	Position of the service place	Loading and other equipments	SLC ID of the loading and other equipment	Paved	Lighting	Size		TAF TSI ID	Name of the track	Usable length (m)	Loading length (m)	Availability of catenary	Axle load (t)	
		From section to section			yes-no-partly	yes-no	Length (m)	Width (m)					yes - no - partly		
Acsád	05249	831-836	none	HU-05249-06-T04	yes	yes	400	40	55-05249-01-IV	IV.	414	400	no	21	Serving is possible only with diesel locomotive.
Ajka	03996	800 - 802	none	HU-03996-06-T14	yes	yes	125	8	55-03996-01-14	14.	416	125	partly	21	
Andráshida	05108	167-80-170+30	none	HU-05108-06-T05	yes	yes	200	5	55-05108-01-5	5.	254	200	no	22,5	
Bak	04937	523+22 - 527+57	none	HU-04937-06-T01B	yes	yes	100	2,5	55-04937-01-1	1.(B)	348	100	no	20	
Bak	04937	523+22 - 527+57	none	HU-04937-06-T01A	yes	yes	140	2,5	55-04937-01-1	1.(A)	348	140	no	20	
Bak	04937	523+22 - 527+57	side loading	HU-04937-19-001	yes	yes	60	2,5	55-04937-01-1	1.(O)	348	60	no	20	
Bakonyzentlászó	02972	349+50- 349+70	side loading	HU-02972-19-001	yes	yes	20	5	55-02972-01-1	1.(O)	372	20	no	21	
Bakonyzentlászó	02972	349+70 - 350+20	none	HU-02972-06-T01	yes	yes	50	8	55-02972-01-1	1.	372	50	no	21	
Beled	02402	337 - 342	side loading	HU-02402-19-001	yes	yes	500	20	55-02402-01-1	1/a	679	500	partly	21	
			loading area	HU-02402-06-T01	yes	yes	20	20	55-02402-01-1	1/b	679	20			
Bősárkány	02360	652 - 656	loading area	HU-02360-06-T01	yes	yes	350	10	55-02360-01-1	1/a	643	350	partly	21	
			side loading	HU-02360-19-001	yes	yes	25	5	55-02360-01-1	1/b	643	25			
		718-720	loading area	HU-05231-06-T07	yes	yes	180	40	55-05231-01-VII	VII.	196	180	no	21	
Bük	05231	720-721	loading area, end loading	HU-05231-19-H08	yes	yes	108	40	55-05231-01-VIII	VIII.	108	108	no	21	
Csákydoroszló	02295	1503 - 1505	loading area	HU-02295-06-T04	no	yes	50	20	55-02295-01-IV	IV.	55	50	no	21	
		1503 - 1502	loading area	HU-02295-06-T06	no	yes	50	10	55-02295-01-VI	VI.	64	50	no	21	
Csorna	02576	304 - 306	loading area	HU-02576-06-T01A	yes	yes	100	5	55-02576-01-1/A	1/A	335	100	yes	21	
		309 - 310	loading area	HU-02576-06-T01B	yes	yes	50	5	55-02576-01-1/B	1/B	218	50	yes	21	
		313 - 317	loading area	HU-02576-06-T17	yes	no	400	5	55-02576-01-XVII	XVII.	578	400	no	21	
Csőmóder - Páka	04960	761+90 - 764+98	side loading	HU-04960-19-001	no	no	150	2,5	55-04960-01-1	1.(O)	254	150	no	20	
Devecser	04044	922+45 - 923+90	none	HU-04044-06-T01	yes	no	145	26	55-04044-01-1	1.	623	145	no	21	
Devecser	04044	919+80 - 921+20	none	HU-04044-06-T08	yes	no	72	17	55-04044-01-8	8.	91	72	no	21	
Egyed-Rábacsanak	03087	248+36 - 248+53	side loading	HU-03087-19-001	yes	yes	17	6	55-03087-01-1	1.(O)	285	17	no	21	
Egyed-Rábacsanak	03087	246+63 - 248+36	none	HU-03087-06-T01	yes	no	173	33	55-03087-01-1	1.	285	173	no	21	
Enese	02535	163 - 165	loading area	HU-02535-06-T01	yes	yes	200	5	55-02535-01-1	1.	670	200	yes	21	
Fertőszentmiklós	02667	602 - 603	loading area, end loading	HU-02667-19-H08	yes	yes	140	10	55-02667-01-VIII	VIII.	149	140	no	21	
		602 - 603	loading area	HU-02667-06-T09	yes	yes	25	25	55-02667-01-IX	IX.	137	25	no	21	
Gecse-Gyarmat	2105	309+92-311+91	none	HU-02105-06-T01	yes	yes	199	10	55-02105-01-1	1.	710	199	no	21	
Gelse	05454	1793+96 - 1794+96	none	HU-05454-06-T04A	yes	yes	100	20	55-05454-01-4	4.(A)	700	100	no	21	
Gelse	05454	1793+47 - 1793+71	side loading	HU-05454-19-004	yes	yes	24	12	55-05454-01-4	4.(O)	700	24	no	21	Loading area can't be used between 14.12.2025 - 12.12.2026. Capacity can not be requested.
Gelse	05454	1791+80 - 1793+20	none	HU-05454-06-T04B	no	no	140	26	55-05454-01-4	4.(B)	700	140	no	21	
Guttorfőde	04952	674+18 - 676+72	side loading	HU-04952-19-001	no	no	18	7	55-04952-01-1	1.(O)	208	18	no	20	
Ják - Főfőde	04952	674+18 - 676+72	none	HU-04952-06-T01	no	no	120	7	55-04952-01-1	1.	208	120	no	20	
Gyékényes	06437	154+60-155+58	none	HU-06437-06-T21	yes	yes	98	7	55-06437-01-21	21.	98	98	no	21	
Gyékényes	06437	157+78-159+07	side loading	HU-06437-19-001	yes	yes	129	22	55-06437-01-1	1.(O)	545	129	no	21	wagon weigh
Gyömöre	02089	258- 258+30	end loading	HU-02089-19-H05	yes	yes	30	10	55-02089-01-5	5.(H)	30	30	no	21	Loading track closed
Gyömöre	02089	258- 258+30	side loading	HU-02089-19-001	yes	yes	30	10	55-02089-01-1	1.(O)	690	30	no	21	Loading track closed
Gyömöre	02089	252+76 - 254+00	none	HU-02089-06-T01	yes	yes	120	12	55-02089-01-1	1.	120	80	no	21	Track 1 can be used as a dead-end track.
Győr-Gysev	02501	2 - 3	loading area	HU-02501-06-T01	yes	no	100	10	55-02505-01-1	1/a	420	100	no	21	
		2 - 3	side loading	HU-02501-19-001	yes	no	50	15	55-02505-01-1	1/b	420	50	no	21	
Győrszabadhegy	02022	37+50-37+71	end loading	HU-02022-19-HJC	yes	yes	21	5	55-02022-01-JÁKI	Jáki csonka(H)	326	326	no	21	"K" signed Loading area can't be used, capacity is not available.
Győrszabadhegy	02022	39+50-42	none	HU-02022-06-T01	yes	yes	250	5	55-02022-01-1	01.	430	250	no	21	"K" signed
Győrszemere	02055	159+02 - 160+02	none	HU-02055-06-T04	yes	yes	100	8,5	55-02055-01-4	4.	370	100	no	21	
Hajmáskér	03939	364+50-365+20	side loading	HU-03939-19-001	yes	yes	138	10	55-03939-01-1	1.(O)	594	138	yes	21	
Hajmáskér	03939	365+20-367	side loading	HU-03939-19-X07	yes	yes	138	10	55-03939-01-7	7.(O)	121	26	partly	21	Serving is possible only with diesel locomotive.
Hajmáskér	03939	365+20-367	end loading	HU-03939-19-H07	yes	yes	138	10	55-03939-01-7	7.(H)	121	26	partly	21	Serving is possible only with diesel locomotive.
Hajmáskér	03939	363+80-367	none	HU-03939-06-T07	yes	yes	250	10	55-03939-01-7	7.	121	95	partly	21	Serving is possible only with diesel locomotive.
Hajmáskér	03939	364+40 - 367+40	none	HU-03939-06-T08	yes	yes	300	13	55-03939-01-8	8.	362	262	partly	21	Serving is possible only with diesel locomotive.
Hegyfalu	02469	147 - 150	loading area	HU-02469-06-T04	yes	yes	306	6	55-02469-01-IV	IV/a	404	306	partly	21	
		149 - 150	side loading	HU-02469-19-004	yes	yes	10	6	55-02469-01-IV	IV/b	404	10			
Hérend	03954	586+60 -587+50	none	HU-03954-06-T10	yes	yes	90	10	55-03954-01-10	10.	90	65	no	21	
Hérend	03954	586+60 -587+50	end loading	HU-03954-19-H10	yes	yes	60	15	55-03954-01-10	10.(H)	90	25	no	21	
Hérend	03954	586+00 - 586+60	side loading	HU-03954-19-001	yes	yes	60	15	55-03954-01-1	1.(O)	668	60	yes	21	
Hérend	03954	579+68 -580+18	end loading	HU-03954-19-H08	yes	yes	20	6	55-03954-01-8	8.(H)	18	20	no	21	
Hérend	03954	579+78 - 582+98	none	HU-03954-06-T08	yes	yes	20	6	55-03954-01-8	8.	20	20	no	21	
Hérend	03954	583+68 -583+88	end loading	HU-03954-19-H06	yes	yes	20	6	55-03954-01-6	6.(H)	300	20	no	21	
Hérend	03954	583+88 - 585+88	none	HU-03954-06-T06	yes	yes	200	6	55-03954-01-6	6.	300	180	no	21	
Hérend	03954	585+88 - 586+28	side loading	HU-03954-19-006	yes	yes	40	6	55-03954-01-6	6.(O)	300	40	no	21	
02261 Ják - Balogunyom	02261	1244 - 1243	loading area	HU-02261-06-T07	no	yes	100	20	55-02261-01-VII	VII.	100	100	no	21	
Jánosbáza	04705	81+00-82+50	none	HU-04705-06-T01	yes	yes	150	6	55-04705-01-1	1.	432	150	no	21	
Jánosomorja	02345	792-793	loading area	HU-02345-06-T05	no	yes	150	10	55-02345-01-V	V.	273	150	no	21	
Kerta	04085	1081 - 1084	none	HU-04085-06-T01	yes	yes	100	10	55-04085-01-1	1.	484	100	no	21	
Keszthely	04747	248+91 - 249+51	none	HU-04747-06-T07B	yes	yes	60	7,5	55-04747-01-7b	7.b.	200	60	partly	21	
		458 - 463	loading area	HU-02626-06-T06	no	yes	500	10	55-02626-01-VI	VI.	608	500	partly	21	

Service place	Code of the service place	Open access loading place registered by GYSEV Zrt.								Loading track next to loading places						Restrictions, remarks
		Position of the service place	Loading and other equipments	SLC ID of the loading and other equipment	Paved	Lighting	Size		TAF TSI ID	Name of the track	Usable length (m)	Loading length (m)	Availability of catenary	Axle load (t)		
		From section to section			yes-no-partly	yes-no	Length (m)	Width (m)					yes - no - partly			
Kapuvár	02626	461 - 462	loading area, end loading	HU-02626-19-H08	yes	yes	20	15	55-02626-01-VIII	VIII.	42	20	no	21		
Könyv	02543	217 - 219	loading area	HU-02543-06-T01	yes	no	150	3	55-02543-01-I	I.	401	150	yes	21	10 km/h	
Körmend	02287	1412 - 1416	loading area	HU-02287-06-T01	yes	yes	150	20	55-02287-01-I/A	I.A	394	150	no	21		
		1412 - 1414	loading area	HU-02287-06-T11	yes	yes	124	20	55-02287-01-XI	XI.	124	124	no	20		
Lenti	04986	853+53 - 862+24	none	HU-04986-06-T01	yes	yes	60	6	55-04986-01-I	1.	593	60	no	20		
Lenti	04986	853+53 - 862+24	side loading	HU-04986-19-001	yes	yes	60	6	55-04986-01-1	1.(O)	593	60	no	20		
Lenti	04986	0+00 - 3+94	none	HU-04986-06-TKCS	yes	yes	300	2	55-04986-01-K csonk	Kerti csonka	490	300	no	20		
Lövő	05207	573-576	loading area	HU-05207-06-T04	yes	yes	250	30	55-05207-01-IV	IV.	294	250	no	21		
Mezőlak	02139	519+51 - 521+10	none	HU-02139-06-T05	yes	yes	159	26	55-02139-01-5	5.	251	159	no	21		
Mezőlak	02139	521+60 - 521+92	none	HU-02139-06-T01	yes	yes	250	3,5	55-02139-01-1	1.	699	250	no	21		
Mezőlak	02139	521+10 - 521+60	side loading	HU-02139-19-001	yes	yes	50	6	55-02139-01-1	1.(O)	699	50	no	18,5		
Murakeresztúr	03640	2340+75-2341+10	side loading	HU-03640-19-0513	yes	yes	35	10	55-03640-01-SZ 13	Sz.13.(O)	210	35	yes	21		
Murakeresztúr	03640	2347+92-2344+77	none	HU-03640-06-TA1	yes	yes	120	6	55-03640-01-A1	A1	315	120	no	21	Serving is possible only with diesel locomotive	
Nagyecen	05173	449-450	loading area	HU-05173-06-T04	yes	yes	150	15	55-05173-01-IV	IV.	215	150	no	21		
Nagykanizsa	03624	2210+10-2210+85	none	HU-03624-06-T16A	no	yes	75	8	55-03624-01-16/a	16/a	120	70	no	21	Capacity can only be requested for picking out overweight and adjustment of consignment.	
Nagykanizsa	03624	2207+77-2210+17	none	HU-03624-06-T19	yes	yes	240	24	55-03624-01-19	19.	271	240	no	21	Serving is possible only with diesel locomotive.	
Nagykanizsa	03624	2207+59-2207+77	end loading	HU-03624-19-H19	yes	yes	18	5	55-03624-01-19	19.(H)	271	18	no	21	Serving is possible only with diesel locomotive.	
Nagykanizsa	03624	2210+18-2211+58	none	HU-03624-06-T22	yes	yes	140	3/15	55-03624-01-22	22.	204	140	no	21	Serving is possible only with diesel locomotive.	
Nagykanizsa	03624	2207+50-2209+10	side loading	HU-03624-19-024	yes	yes	160	5,6	55-03624-01-24	24.(O)	238	105	no	21	Serving is possible only with diesel locomotive.	
Nagykanizsa	03624	2209+65-2210+15	none	HU-03624-06-T25	yes	yes	50	24	55-03624-01-25	25.	76	50	no	21	Serving is possible only with diesel locomotive.	
Óriszentpéter	05074	356 - 358	none	HU-05074-06-T08	yes	yes	200	12,5	55-05074-01-8	8.	217	200	partly	22,5	Serving is possible only with diesel locomotive.	
Pácsony	05330	1292 - 1294	loading area	HU-05330-06-T04	yes	yes	188	14	55-05330-01-IV	IV.	188	188	no	21		
Pannonhalma	02931	150+50 - 152+25	none	HU-02931-06-T01	yes	yes	175	13	55-02931-01-1	1.	365	175	no	21		
Pannonhalma	02931	152+25 - 152+45	side loading	HU-02931-19-001	yes	yes	20	5	55-02931-01-1	1.(O)	365	20	no	21		
Pápa	02121	445+80 - 447+30	none	HU-02121-06-T09	yes	yes	150	15	55-02121-01-9	9.	234	150	no	21		
Pápa	02121	445+80 - 447+30	none	HU-02121-06-T15	yes	yes	150	15	55-02121-01-15	15.	372	150	no	21		
Pápa	02121	444+75 - 446+40	none	HU-02121-06-T01	yes	yes	165	10	55-02121-01-1	1.	430	165	no	21		
Pápa	02121	446+92 - 447+17	end loading	HU-02121-19-H01	yes	yes	25	4	55-02121-01-1	1.(H)	430	25	no	21		
Pápa	02121	445+10 - 447+40	none	HU-02121-06-T10	yes	yes	230	10	55-02121-01-10	10.	320	230	no	21		
Papkeszi	04192	83 - 83+60	none	HU-04192-06-T01	no	no	60	10	55-04192-01-1	no	299	60	no	21	Excluded from traffic.	
Pétfürdő	03921	261+90 - 262+50	side loading	HU-03921-19-001	no	yes	60	10	55-03921-01-1	1.(O)	478	60	yes	21		
Pinnye	02683	673 - 675	side loading	HU-02683-19-001	yes	yes	20	2	55-02683-01-1	I/a	429	20	yes	21		
			loading area	HU-02683-06-T01	yes	yes	200	5	55-02683-01-1	I/b	429	200	yes	21		
Rajka	01974	1071-1072	side loading	HU-01974-19-001	yes	yes	25	10	55-01974-01-1	I/a	810	25	yes	21		
			loading area	HU-01974-06-T01	yes	yes	150	15	55-01974-01-1	I/b	810	150	yes	21		
Rábapordány	03095	288+97 - 291+13	none	HU-03095-06-T01	yes	no	216	27	55-03095-01-1	1.	314	216	no	21		
Rábatamási	02592	371 - 372	loading area	HU-02592-06-T03	yes	no	120	10	55-02592-01-III	III.	168	120	no	21		
Sárvár	02212	908+75 - 910+65	none	HU-02212-06-T01	yes	yes	190	7	55-02212-01-1	1.	172/727	160	partly	21	can only be served from the endpoint.	
Sárvár	02212	918+45 - 919+25	none	HU-02212-06-T12	no	no	80	20	55-02212-01-12	12.	101	80	no	21	Serving is possible only with diesel locomotive.	
Sárvár	02212	914+50 - 916+92	none	HU-02212-06-T11	yes	yes	242	25	55-02212-01-11	11.	874	242	partly	21	Serving is possible only with diesel locomotive.	
Sopron-Rendező	48025	9 - 16	loading area	HU-48025-06-T01	yes	yes	650	5	55-48025-01-1	I.	731	650	no	21		
Sümeg	04663	258 - 261	side loading	HU-04663-19-004	no	no	60	5	55-04663-01-4	4.(O)	361	60	no	21	Excluded from traffic.	
Sümeg	04663	258 - 261	none	HU-04663-06-T04	no	yes	130	8	55-04663-01-4	4.	361	130	no	20		
Szany-Rabaszentandrás	03079	177+92 - 182+37	none	HU-03079-06-T01	yes	no	445	10-36	55-03079-01-1	1.	473	268, 116	no	21		
Szentgál	03962	639+80 - 640+80	none	HU-03962-06-T01	no	yes	100	8	55-03962-01-1	1.	645	100	no	21		
Szentgotthárd	02329	1693 - 1692	loading area	HU-02329-06-T10	yes	yes	90	10	55-02329-01-X	X.	98	90	no	21		
		1693 - 1694	loading area	HU-02329-06-T11	no	yes	50	10	55-02329-01-XI	XI.	89	50	no	21		
Szil-Sopronnémeti	02378	461 - 463	loading area	HU-02378-06-T01	yes	yes	277	20	55-02378-01-1	1.	301	277	partly	21		
		961-964	loading area	HU-03778-06-TUK	yes	no	230	30	55-03778-01-UJKHÜZÖ	újkhívező	238	230	no	21		
		957-959	side loading	HU-03778-19-ORM	yes	yes	80	20	55-03778-01-RAMPA	rampa	185	80	no	21		
Szombathely Rendező	43778	967 - 970	loading area	HU-03778-06-TK1	yes	no	80	30	55-03778-01-KPU_I	Konténer PU I/a	270	80	partly	21	without electric power	
			side+end loading	HU-03778-19-XK1	yes	no	150	30	55-03778-01-KPU_I	Konténer PU I/b	270	150	partly	21		
		967 - 970	loading area	HU-03778-06-TK2	yes	no	230	15	55-03778-01-KPU_II	Konténer PU. II.	273	230	partly	21	without electric power	
Tapolca	04598	447+99 - 446+71	none	HU-04598-06-T33	yes	yes	128	10	55-04598-01-33	33.	128	128	no	21		
Tapolca	04598	449+03 - 449+63	side loading	HU-04598-19-001	yes	yes	60	15	55-04598-01-1	1.(O1)	618	60	no	21		
Tapolca	04598	449+03 - 449+63	end loading	HU-04598-19-H14	yes	yes	60	15	55-04598-01-14	14.(H1)	55	15	no	21		
Tarjánpuszta	02949	212+57 - 213+42	none	HU-02949-06-T01A	yes	yes	85	15	55-02949-01-1	1.(A)	375	85	no	21		
Tarjánpuszta	02949	213+42 - 213+62	side loading	HU-02949-19-001	yes	yes	20	5	55-02949-01-1	1.(O)	375	20	no	21		
Tarjánpuszta	02949	214+25 - 215	none	HU-02949-06-T01B	yes	yes	75	15	55-02949-01-1	1.(B)	375	75	no	21		
Tarjánpuszta	02949	215+10 - 215+50	none	HU-02949-06-T01C	no	yes	40	14	55-02949-01-1	1.(C)	375	40	no	21		
Tarjánpuszta	02949	215+50 - 215+90	none	HU-02949-06-T01D	yes	yes	70	14	55-02949-01-1	1.(D)	375	70	no	21		
Ukk	04689	164+33 - 164+38	none	HU-04689-06-T07	yes	yes	225	7	55-04689-01-7	7.	225	225	no	21		
Uzsabánya	04648	32+54-33+90	one (under reconstructi	HU-04648-06-T06	yes	yes	135	8	55-04648-01-6	6.	208	135	no	20		
Városlőd-Kislőd	03988	740 - 740+90	none	HU-03988-06-T01A	yes	yes	90	11	55-03988-01-1	1.(A)	616	90	partly	21	Serving is possible only with diesel locomotive.	
Városlőd-Kislőd	03988	740 +90- 741+20	side loading	HU-03988-19-001	yes	yes	30	11	55-03988-01-1	1.(O)	616	30	partly	21	Serving is possible only with diesel locomotive.	
Városlőd-Kislőd	03988	742+50 - 743+50	none	HU-03988-06-T01B	yes	yes	100	6	55-03988-01-1	1.(B)	616	100	partly	21	Serving is possible only with diesel locomotive.	

Service place	Open access loading place registered by GYSEV Zrt.								Loading track next to loading places						Restrictions, remarks
	Code of the service place	Position of the service place	Loading and other equipments	SLC ID of the loading and other equipment	Paved	Lighting	Size		TAF TSI ID	Name of the track	Usable length (m)	Loading length (m)	Availability of catenary	Axle load (t)	
		From section to section			yes-no-partly	yes-no	Length (m)	Width (m)					yes - no - partly		
Várpalota	03871	216+70 - 218	side loading	HU-03871-19-001	yes	yes	130	15	55-03871-01-1	1.(O1)	619	130	partly	21	Serving is possible only with diesel locomotive.
Várpalota	03871	216+10 - 216+70	end loading	HU-03871-19-H13	yes	yes	60	9	55-03871-01-13	13.(H1)	172	60	partly	21	Serving is possible only with diesel locomotive.
Várpalota	03871	216+10 - 218+00	none	HU-03871-06-T14	yes	yes	190	9	55-03871-01-14	14.	305	190	no	21	
Várpalota	03871	221+80-223+50	none	HU-03871-06-T15	yes	yes	145	10	55-03871-01-15	15.	145	145	no	21	
Vasvár	05314	1186 - 1188	loading area	HU-05314-06-T03	yes	yes	200	10	55-05314-01-III	III.	30	200	no	21	
Vaszár	02113	370+50 - 371+00	none	HU-02113-19-001	yes	yes	140	20	55-02113-01-1	1.(O)	685	140	no	21	
Vaszár	02113	372+52-374+54	none	HU-02113-06-T01	yes	yes	202	29	55-02113-01-1	1.	685	202	no	21	
Veszprém	03947	447 - 448	nincs	HU-03947-06-TK01	igen	igen	250	16	55-03947-01-K1	K1.	253	250	nem	21	K2 felüli oldal
Veszprém	03947	445 - 446	nincs	HU-03947-06-TK02A	igen	igen	100	16	55-03947-01-K2	K2.(A)	259	100	nem	21	K1 felüli oldal Útközbak-Mérlegház között
Veszprém	03947	447+40 - 448	nincs	HU-03947-06-TK02B	igen	igen	60	16	55-03947-01-K2	K2.(B)	259	60	nem	21	K1 felüli oldal Mérlegház-1/2-s váltó között
Veszprém	03947	447+50 - 448	nincs	HU-03947-06-TK02C	igen	igen	50	16	55-03947-01-K2	K2.(C)	259	50	nem	21	K3 felüli oldal
Veszprém	03947	447+50 - 448	nincs	HU-03947-06-TK03A	igen	igen	50	16	55-03947-01-K3	K3.(A)	258	50	nem	21	K2 felüli oldal
Veszprém	03947	447 - 448	nincs	HU-03947-06-TK03B	igen	igen	100	16	55-03947-01-K3	K3.(B)	258	100	nem	21	K4 felüli oldal
Veszprém	03947	447 - 448	nincs	HU-03947-06-TK04	igen	igen	100	16	55-03947-01-K4	K4	260	100	nem	21	K3 felüli oldal
Veszprémvarsány	02964	285+85 - 286+75	none	HU-02964-06-T01	yes	yes	90	17	55-02964-01-1	1.	290	90	no	21	
Veszprémvarsány	02964	286+75 - 287+25	side loading	HU-02964-19-001	yes	yes	50	14	55-02964-01-1	1.(O)	290	50	no	21	
Veszprémvarsány	02964	279+80 - 280+95	none	HU-02964-06-T07	yes	yes	115	17	55-02964-01-7	7.	115	115	no	21	
Vinár	02154	590+72 - 592+10	side loading	HU-02154-19-001	no	yes	138	4,5	55-02154-01-1	1.(O)	450	138	no	21	
Zalabér - Batyk	04846	310+50 - 311+50	none	HU-04846-06-T06	yes	yes	100	10	55-04846-01-6	6.	360	100	no	21	
Zalaegerszeg	04895	4+12 - 3+57	side and end loading	HU-04895-19-XX01	yes	yes	45	8	55-04895-01-Ker 1	Ker.telep1.(OH)	180	45	no	20	
Zalaegerszeg	04895	3+04 - 1+24	none	HU-04895-06-TK02	yes	yes	180	10	55-04895-01-Ker 2	Ker.telep2.	180	180	no	20	
Zalaegerszeg	04895	3+04 - 1+24	none	HU-04895-06-TK03	yes	yes	170	15	55-04895-01-Ker 3	Ker.telep3.	170	170	no	20	
Zalaegerszeg	04895	3+93 - 2 +23	none	HU-04895-06-TK04	yes	yes	170	4	55-04895-01-Ker 4	Ker.telep4.	170	170	no	20	
Zalahaláp	04606	46+75 - 46+95	end loading	HU-04606-19-H01	no	no	20	10	55-04606-01-1	1.(H)	120	20	no	0	Loading area can't be used, because the section Zalahaláp-ERDÉSZET ipvk.pvh. - Zalahaláp is impassable.
Zalahaláp	04606	45+65-46+25	none	HU-04606-06-T01	no	no	60	10	55-04606-01-1	1.	120	60	no	0	Loading area can't be used, because the section Zalahaláp-ERDÉSZET ipvk.pvh. - Zalahaláp is impassable.
Zalakomár	03657	2002+25 - 2002+79	side loading	HU-03657-19-004	yes	yes	54	5,5	55-03657-01-4	4.(O)	369	54	partly	21	Serving is possible only with diesel locomotive
Zalakomár	03657	1996+63 - 1999+46	none	HU-03657-06-T04A	no	yes	283	6	55-03657-01-4	4.(A)	273	273	no	21	Serving is possible only with diesel locomotive
Zalakomár	03657	1999+46 - 2003+07	none	HU-03657-06-T04B	yes	yes	361	23,5	55-03657-01-4	4.(B)	369	307	no	21	Serving is possible only with diesel locomotive
Zalalövő	05033	230 - 232	side and end loading	HU-05033-19-X08	yes	yes	40	10	55-05033-01-8	8.(OH)	230	40	partly	22,5	Serving is possible only with diesel locomotive.
Zalalövő	05033	230 - 232	none	HU-05033-06-T10	yes	yes	100	10	55-05033-01-10	10.	150	100	no	22,5	
Zalaszentgrót	04721	60 - 62	side loading	HU-04721-19-001	no	yes	45	12	55-04721-01-1	1.(O)	314	45	no	21	
Zalaszentgrót	04721	60 - 62	wage	HU-04721-06-T01	yes	yes	50	12	55-04721-01-1	1.	314	50	no	21	
Zalaszentgrót	04721	59 - 62	none	HU-04721-06-T04	yes	yes	234	13	55-04721-01-4	4.	239	234	no	21	
Zalaszentiván	05371	475+20 -475+70	none	HU-05371-06-T09	yes	yes	50	18	55-05371-01-9	9.	115	50	no	21	
Zalaszentmihály - Pacsa	05413	1645 - 1650	none	HU-05413-06-T05A	yes	yes	70	11	55-05413-01-5	5.(A)	583	70	no	21	
Zalaszentmihály - Pacsa	05413	1645 - 1650	none	HU-05413-06-T05B	yes	yes	244	15	55-05413-01-5	5.(B)	583	244	no	21	
Zalaszentmihály - Pacsa	05413	1645 - 1650	none	HU-05413-06-T05C	yes	no	132	15	55-05413-01-5	5.(C)	583	132	no	21	
Zirc	02998	516+70-517+50	none	HU-02998-06-T07	no	yes	80	8	55-02998-01-7	7.	325	80	no	18,5	